

Server Administrator Version 7.4 Installation Guide



Notes, Cautions, and Warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright

Copyright © 2014 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2014 - 03

Rev. A00

Contents

1 Introduction.....	7
What Is New In This Release.....	7
Software Availability.....	8
Systems Management Software.....	8
Server Administrator Components On A Managed System.....	8
Security Features.....	10
Other Documents You Might Need.....	11
2 Preinstallation Setup.....	13
Installation Requirements.....	13
Supported Operating Systems And Web Browsers.....	13
System Requirements.....	13
Managed System Requirements.....	13
Supported Systems Management Protocol Standards.....	14
Configuring SNMP Agents.....	14
Remote Enablement Requirements.....	15
Dependent RPMs For Remote Enablement.....	15
Post Installation Configuration For Remote Enablement.....	16
Winbind Configuration For openwsman And sfcf For Red Hat Enterprise Linux Operating Systems.....	18
Workaround For The Libssl Issue.....	18
Winbind Configuration For openwsman And sfcf For SUSE Linux Enterprise Server Operating System.....	19
3 Installing Managed System Software On Supported Linux And VMware ESX.....	21
Software License Agreement.....	22
RPM For Individual Components.....	22
OpenIPMI Device Driver.....	27
Degradation Of Functionality When The Server Administrator Instrumentation Service Is Started.....	27
Installing Managed System Software.....	27
Prerequisites For Installing Managed System Software.....	28
Installing Managed System Software Using The Provided Media.....	28
Server Administrator Custom Installation Utility.....	32
Managed System Software Installation Using Third Party Deployment Software.....	33
Uninstalling Managed System Software.....	35
Uninstalling Managed System Software Using The Uninstall Script.....	35

Uninstalling Managed System Software Using The RPM Command.....	35
4 Installing Systems Management Software On VMware ESXi.....	37
Using The vSphere CLI.....	37
Using The VMware vSphere Management Assistant (vMA).....	38
Using The VMware Update Manager (VUM).....	38
Using The Power CLI.....	39
Accessing Server Administrator on VMware ESXi.....	40
Enabling Server Administrator Services On The Managed System.....	40
Enabling CIM OEM Providers Using vSphere Client (For VMware ESXi 4.0/ESXi 4.1).....	40
Enabling CIM OEM Providers Using vSphere CLI (For VMware ESXi 4.0/ESXi 4.1).....	41
Enabling CIM OEM Providers Using vMA (For VMware ESXi 4.0/ESXi 4.1).....	41
Uninstalling The Existing Systems Management VIB.....	42
Configuring The SNMP Agent On Systems Running VMware ESXi.....	42
Configuring The System To Send Traps To A Management Station Using The vSphere CLI....	42
Troubleshooting.....	43
5 Frequently Asked Questions.....	45
What ports do systems management applications use?.....	45
When I run virtual media on the DRAC controller over a Wide Area Network (WAN) with low bandwidth and latency, launching Systems Management Install directly on the virtual media failed, what do I do?.....	45
Do I need to uninstall the Adaptec Fast Console application installed on the system before installing the Server Administrator Storage Management Service?.....	45
Red Hat Enterprise Linux or SUSE Linux Enterprise Server.....	45
After installing Server Administrator, I cannot log in.....	45
I see the following message when I try to install Server Administrator on a guest Linux operating system.....	45
I manually installed my Red Hat Enterprise Linux 4 64-bit operating system and can see RPM dependencies while installing Server Administrator. Where can I find these dependent RPM files?.....	46
I have performed a non-default install of the Linux operating system using the Linux operating system media, I see missing RPM file dependencies while installing Server Administrator?.....	46
Where can I find the source packages for Open Source RPMs?.....	46
What do I do when management station RAC utility installation fails due to missing RPM file?.....	46
When using the rpm -e 'rpm -qa grep srvadmin' command to remove systems management software, some RPM utility versions may schedule an uninstallation in an incorrect order, which results in users encountering misleading warning or error messages. What is the solution?.....	47
What do I do when I am asked to authenticate using the root user account?.....	47

Why am I getting a warning concerning the RPM package key during installation?.....	47
What are the names of all the Systems Management features under Red Hat Enterprise Linux or SUSE Linux Enterprise Server?.....	47
What do the directories under srvadmin/linux/custom/<operating system> contain?.....	48
What are the additional components that can be installed on a system that already has Server Administrator installed?.....	53
What happens if I install the RPM package on an unsupported system or on an unsupported operating system?.....	53
What daemons run on Red Hat Enterprise Linux and SUSE Linux Enterprise Server operating systems after Server Administrator is started?.....	53
What kernel modules are loaded when Server Administrator is started?.....	54
When I run srvadmin-cm (Server Administrator Inventory Collector) it displays error messages. What do I do?.....	55
Emulex Network Adpater is not detected on Red Hat Enterprise Linux operating system. What do I do?.....	55
6 Linux Installer Packages.....	57

Introduction

This topic provides information on:

- Installing Server Administrator on managed systems.
- Installing and using the Remote Enablement feature.
- Managing remote systems using Server Administrator Web Server.
- Configuring the system before and during a deployment or upgrade.



NOTE: If you are installing management station and managed system software on the same system, install identical software versions to avoid system conflicts.

What Is New In This Release

The release highlights of Server Administrator are:

- Added support for the following operating systems:
 - Novell SUSE Linux Enterprise Server 11 SP3 (64-bit)
 - VMware vSphere 5.0 U3, 5.1 U2, and 5.5
 - Red Hat Enterprise Linux 6.5 (64-bit)
- Added support for web browsers:
 - Mozilla Firefox versions 22 and 23
 - Internet Explorer version 11
 - Google Chrome version 27, 28, 30, and 31
 - Safari version 6.0
- Support for 64-bit Inventory Collector RPM (srvadmin-cm) on supported Linux operating system.
- Support for server-based monitoring on servers installed in Dell PowerEdge FX2 series chassis.
- Support for displaying Node ID in System/Server Module Summary information.
See Dell OpenManage Server Administrator Command Line Interface Guide.
- Support for new values for form factor aligning to iDRAC values.
See Dell OpenManage Server Administrator Command Line Interface Guide.
- Introduction of PowerEdge RAID Controller (PERC) 9 — PERC H730P Adapter
 - Support for RAID Level 10 Virtual Disk Creations With Uneven Span
 - Support for 4K sector hard-disk drives — Advanced Format Standard
 - Support for data protection using T10 Standard Protection Information (PI) — Data Integrity Field

For more information on PERC H730P Adapter, see *Dell OpenManage Server Administrator Storage Management User's Guide*

- A link to the complete overview of OpenManage products which provides more information on what is available in the Systems Management Tools and Documentation (SMTD) DVD, what is embedded in the server, and what can be downloaded from **dell.com/support**

Software Availability

The Server Administrator software can be installed from:

- Systems Management Tools and Documentation DVD
- Support site — For more information, see **dell.com/support**.
- VMware Update Manager (VUM) — For more information, see **http://vmwaredepot.dell.com/**.
- Linux Repository using YUM, rug, or zypper — For more information, see [Linux Repository](#).

Systems Management Software

Systems management software is a suite of applications that enables you to manage the systems with proactive monitoring, notification, and remote access.

Systems management software comprises of two DVDs:

- *Systems Management Tools and Documentation*
- *Server Update Utility*

 **NOTE:** For more information on these DVDs, see *Systems Management Tools And Documentation <Version Number> Installation Guide*.

Server Administrator Components On A Managed System

The setup program provides the following options:

- Custom Setup
- Typical Setup

The custom setup option enables you to select the software components you want to install. The table lists the various managed system software components that you can install during a custom installation.

Table 1. Managed System Software Components

Component	What is installed	Deployment Scenario	Systems to install on
Server Administrator Web Server	Web-based Systems Management functionality that enables you to manage systems locally or remotely.	Install only if you want to remotely monitor the managed system. You do not require physical access to the managed system.	Any system. For example, laptop or desktops.
Server Instrumentation	Server Administrator Instrumentation Service	Install to use the system as the managed system. Installing Server Instrumentation and the Server Administrator Web Server installs Server Administrator. Use Server Administrator	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> at dell.com/support/manuals .

Component	What is installed	Deployment Scenario	Systems to install on
		to monitor, configure, and manage the system.	
		 NOTE: If you choose to install only Server Instrumentation, you must also install one of the Management Interfaces or the Server Administrator Web Server.	
Storage Management	Server Administrator Storage Management	Install to implement hardware RAID solutions and configure the storage components attached to the system. For more information on Storage Management, see the <i>Server Administrator Storage Management User's Guide</i> in the docs directory.	Only those systems on which you have installed Server Instrumentation or the Management Interfaces.
Command Line Interface (Management Interface)	Command Line Interface of Server Instrumentation	Install to provide local and remote system management solutions to manage Server and Storage instrumentation data using command-line interfaces.	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> .
WMI (Management Interface)	Windows Management Instrumentation Interface of Server Instrumentation	Install to provide local and remote system management solutions to manage Server data using WMI protocol.	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> .
SNMP (Management Interface)	Simple Network Management Protocol Interface of Server Instrumentation	Install to provide local and remote system management solutions to manage Server and Storage instrumentation data using SNMP protocol.	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> .
Remote Enablement (Management Interface)	Instrumentation Service and CIM Provider	Install to perform remote systems management tasks. Install Remote Enablement on one system and Server	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> .

Component	What is installed	Deployment Scenario	Systems to install on
		Administrator Web Server on another system. You can use the system with the Server Administrator to remotely monitor and manage the systems which have Remote Enablement installed.	
Operating System Logging (Management Interface)	Operating System Logging	Install to allow local system management-specific events logging on the operating system for Server and Storage instrumentation. On systems running Microsoft Windows, use the Event Viewer to locally view the collected events.	Supported systems. For a list of supported systems, see the <i>Systems Software Support Matrix</i> .
DRAC Command Line Tools	Hardware application programming interface and iDRAC 12G or iDRAC, DRAC 5, or DRAC 4 (depending on the type of the system)	Install to receive email alerts for warnings or errors related to voltage, temperature, and fan speed. Remote Access Controller also logs event data and the most recent crash screen (available only on systems running Windows operating system) to help you diagnose the probable cause of a system crash.	Only those systems on which you have installed Server Instrumentation or Management Interface.

Security Features

Systems management software components provide these security features:

- Support for Network Information Services (NIS), Winbind, Kerberos, and Lightweight Directory Access Protocol (LDAP) authentication protocols for Linux operating systems.
 - Role-based authority that allows specific privileges to be configured for each user.
-  **NOTE:** Applicable only for systems running Red Hat Enterprise Linux, SUSE Linux Enterprise Server, or VMware ESX/ESXi.
- User ID and password configuration through the web-based interface or the command line interface (CLI), in most cases.
 - SSL encryption (**Auto Negotiate** and **128-bit or higher**).

 **NOTE:** Telnet does not support SSL encryption.

- Session time-out configuration (in minutes) through the web-based interface.
- Port configuration to allow systems management software to connect to a remote device through firewalls.

 **NOTE:** For information about ports that the various systems management components use, see the User Guide for that component.

For information about the Security Management, see the *Server Administrator User's Guide* at dell.com/openmanagemanuals.

Other Documents You Might Need

In addition to this guide, for more information, access the following guides.

- The *Lifecycle Controller 2 Version 1.00.00 User's Guide* provides information on using the Lifecycle Controller.
- The *Management Console User's Guide* provides information about installing, configuring, and using Management Console.
- The *Systems Build and Update Utility User's Guide* provides information on using the Systems Build and Update Utility.
- The *Systems Software Support Matrix* provides information about the various systems, the operating systems supported by these systems, and the systems management components that can be installed on these systems.
- The *Server Administrator User's Guide* describes the installation and use of Server Administrator.
- The *Server Administrator SNMP Reference Guide* documents the SNMP management information base (MIB).
- The *Server Administrator CIM Reference Guide* documents the Common Information Model (CIM) provider, which is an extension of the standard management object format (MOF) file. This guide explains the supported classes of management objects.
- The *Server Administrator Messages Reference Guide* lists the messages that are displayed on the Server Administrator home page Alert log, or on the operating system's event viewer. This guide explains the text, severity, and cause of each alert message that the Server Administrator displays.
- The *Server Administrator Command Line Interface Guide* documents the complete command line interface for Server Administrator, including an explanation of CLI commands to view system status, access logs, create reports, configure various component parameters, and set critical thresholds.
- The *Remote Access Controller 5 User's Guide* provides complete information about installing and configuring a DRAC 5 controller and using DRAC 5 to remotely access an inoperable system.
- The *Integrated Remote Access Controller User's Guide* provides complete information about configuring and using an integrated Remote Access Controller to remotely manage and monitor the system and its shared resources through a network.
- The *Update Packages User's Guide* provides information about obtaining and using the Update Packages for Windows and Linux as part of the system update strategy.
- The *Server Update Utility User's Guide* provides information on using the Server Update Utility.
- The *Systems Management Tools and Documentation DVD* contains readme files for applications found on the media.

 **NOTE:** If the product does not perform as expected or you do not understand a procedure described in this guide, see **Getting Help** in the system's Hardware Owner's Manual.

Preinstallation Setup

Ensure that you perform the following before installing Server Administrator:

- Read the installation instructions for the operating system.
- Read the [Installation Requirements](#) to ensure that the system meets or exceeds the minimum requirements.
- Read the applicable readme files and the *Systems Software Support Matrix*.
- Close all applications running on the system before installing the Server Administrator applications.

On systems running the Linux operating system, ensure that all operating system RPM Package Manager (RPM) packages required by the Server Administrator RPMs are installed. If the system had VMware ESX factory-installed, Red Hat Enterprise Linux, or SUSE Linux Enterprise Server, see the [Dependent RPMs for Remote Enablement](#) section for information on any RPMs that you need to manually install prior to installing managed system software. Typically, manual installation of RPMs is not required.

Installation Requirements

This section describes the general requirements of the Server Administrator and provides information on supported operating systems and web browsers.

 **NOTE:** Prerequisites specific to an operating system are listed as part of the installation procedures.

Supported Operating Systems And Web Browsers

For information on supported operating systems and web browsers, see the *Systems Software Support Matrix*.

 **NOTE:** Ensure that the web browser is configured to bypass the proxy server for local addresses.

System Requirements

Install Server Administrator on each system to be managed. You can manage each system running Server Administrator locally or remotely through a supported web browser.

Managed System Requirements

- One of the supported operating systems and web browser.
- Minimum 2GB RAM.
- Minimum 512MB free hard drive space.
- Administrator rights.
- TCP/IP connection on the managed system and the remote system to facilitate remote system management.
- One of the Supported Systems Management Protocol Standards.

- Monitor with a minimum screen resolution of 800 x 600. The recommended screen resolution is at least 1024 x 768.
- The Server Administrator Remote Access Controller service requires remote access controller (RAC) installed on the managed system. See the relevant *Remote Access Controller User's Guide* for complete software and hardware requirements.
- The Server Administrator Storage Management Service requires Server Administrator installed on the managed system. See the *Server Administrator Storage Management User's Guide* for complete software and hardware requirements.

Related Link:

[Supported Operating Systems and Web Browsers](#)

Supported Systems Management Protocol Standards

Install a supported systems management protocol on the managed system before installing the management station or managed system software. On supported Linux operating system, systems management software supports:

- Common Information Model (CIM)/Windows Management Instrumentation (WMI)
- Simple Network Management Protocol (SNMP)

Install the SNMP package provided with the operating system. If SNMP is installed post Server Administrator installation, restart Server Administrator services.

 **NOTE:** For information about installing a supported systems management protocol standard on the managed system, see the operating system documentation.

The following table shows the availability of the systems management standards for each supported operating system.

Table 2. Availability of Systems Management Protocol by Operating Systems

Operating System	SNMP	CIM/WMI
Supported Red Hat Enterprise Linux operating system.	Install the SNMP package provided with the operating system.	Available. Install the CIM packages provided on the <i>Systems Management Tools and Documentation</i> DVD - SYSMGMT\sradmin\linux\RPMS\supportRPMS\opensource-components .
Supported SUSE Linux Enterprise Server operating system.	Install the SNMP package provided with the operating system.	Available. Install the CIM packages provided on the <i>Systems Management Tools and Documentation</i> DVD - SYSMGMT\sradmin\linux\RPMS\supportRPMS\opensource-components .

 **NOTE:** It is recommended to install the SFCB, SFCC, OpenWSMAN, and CMPI-Devel packages from the operating system media, if available.

Configuring SNMP Agents

The systems management software supports the SNMP systems management standard on all supported operating systems. The SNMP support may or may not be installed depending on the operating system

and how the operating system was installed. An installed supported systems management protocol standard, such as SNMP, is required before installing the systems management software.

Configure the SNMP agent to change the community name, enable set operations, and send traps to a management station. To configure the SNMP agent for proper interaction with management applications, perform the procedures described in the *Server Administrator User's Guide*.

Related Links:

- [Installation Requirements](#)
- [Supported Systems Management Protocol Standards](#)

Remote Enablement Requirements

The Remote Enablement feature is currently supported on:

- Red Hat Enterprise Linux
- Novell SUSE Enterprise Linux
- VMware vSphere (ESX and ESXi)

Dependent RPMs For Remote Enablement

If you choose to install the Remote Enablement feature, you have to install certain dependent RPMs and configure these RPMs before installing the feature. Install the following RPMs:

- **libcmpiCpplImpl0**
- **libwsman1**
- **openwsman-server**
- **sblim-sfcb**
- **sblim-sfcc**

The dependent RPMs are available on the *Systems Management Tools and Documentation* DVD at **srvadmin\linux\RPMS\supportRPMS\opensource-components\<OS>\<arch>**.



NOTE: On supported SLES 11 and above and Red Hat Enterprise Linux 6 and preceding operating systems, it is recommended that you install the RPMs from the operating system media, if available.

Installing Dependent RPMs

To install the dependent RPMs not available on the operating system media:

1. Make sure that Pegasus RPMs are uninstalled.
2. Check if the **openwsmand** and **sfcbd** binaries are already installed using make-install. Check by running the commands: **openwsman** or **sfcbd** or you can check the existence of the binaries in the **/usr/local/sbin** directory.
3. If the binaries are installed, uninstall these binaries.

4. Check for the required dependencies for the **openwsman** and **sfcdb** RPMs listed in the following table.

Table 3. Required Dependencies

Packages	Red Hat Enterprise Server	SUSE Linux Enterprise Server
Openwsman	OpenSSL LibXML Pkgconfig CURL Chkconfig Initscript SBLIM-SFCC	LibOpenSSL LibXML Pkg-config libCURL aaa_base aaa_base SBLIM-SFCC
SBLIM SFCC	CURL	LibCURL
SBLIM SFCB	zlib CURL PAM OpenSSL Chkconfig Initscript	zlib LibCURL PAM LibOpenSSL aaa_base aaa_base

5. Install the dependent RPMs. You can install the RPMs:

- with a single command `rpm -ivh rpm1 rpm2 rpm3 rpm4 ... rpmN`
or
- individually



NOTE: If you are installing RPMs individually, follow this sequence.

```
rpm -ivh sblim-sfcb-x.x.x.rpm  
rpm -ivh sblim-sfcc-x.x.x.rpm
```



NOTE: Install the **libwsman** and **openwsman** client RPMs simultaneously as they have cyclic dependency.

```
rpm -ivh libwsman1-x.x.x.rpm openwsman-client-x.x.x.rpm  
rpm -ivh openwsman-server-x.x.x.rpm
```

Post Installation Configuration For Remote Enablement

This section details the steps to configure the dependent RPMs if you have installed the Remote Enablement feature.

The post-installation configuration script is available at `/opt/dell/srvadmin/etc/` on the server file system.

After installing all the dependent RPMs and the Remote Enablement feature, execute the **autoconf_cim_component.sh** script.



NOTE: The Distributed Web Server (DWS) connection does not work properly, if you have installed the **sblim-sfcb** RPM from SUSE Linux Enterprise Server 11 SP3 operating system DVD. To resolve the connection issue, you must install the **sblim-sfcb** RPM either from SUSE Linux Enterprise Server 11 SP2 operating system DVD or from the *Systems Management Tools and Documentation* DVD.

Before executing the **autoconf_cim_component.sh** script, make sure that Systems Management is installed.

Execute the following command to configure **sfc** and **openwsman** as per the default configurations: `./autoconf_cim_component.sh`

 **NOTE:** To configure **openwsman** on the managed node to run on a different port, use the **-p <port>** option with **autoconf_cim_component.sh**. This is optional and by default the **openwsman** is configured to run on port 443.

Related Links:

[Installing Managed System Software on Supported Linux and VMware ESX](#)

Creating Server Certificate For WSMAN

You can either create a new certificate for WSMAN or reuse an existing certificate.

Creating A New Certificate

You can create a new server certificate for WSMAN by executing the **owsmangencert.sh** script located at **/etc/openwsman**. This script is provided by the **openwsman** RPM. Follow the steps in the wizard to create the server certificate.

Reusing An Existing Certificate

If you have a self-signed or CA-signed certificate, you can use the same certificate for the **openwsman** server by updating the **ssl_cert_file** and **ssl_key_file** values, grouped under **[server]** tag, in **/etc/openwsman/openwsman.conf** with the existing certificate values.

Configuring CRL For The openwsman Client

You need to configure the Certificate Revocation List (CRL) used by Server Administrator Web Server. To do this:

1. Mention a valid CRL file in **/etc/openwsman/openwsman_client.conf**.
2. If left blank, the CRL check is ignored.

 **NOTE:** CRL support is only present on SUSE Linux Enterprise Server version 11 and Red Hat Enterprise Linux Server version 5 update 5. For other operating systems, contact the operating system vendor to provide the required CURL library with CRL support.

Running sfc And openwsman

Run **sfc** and **openwsman**:

- `/etc/init.d/sfc start`
- `/etc/init.d/openwsmand start`

 **NOTE:** On Red Hat Enterprise Linux 6, replace **sfc** with **sblim-sfc**.

On Red Hat Enterprise Linux 6, for the **sblim-sfc** and **openwsman** to start automatically after a reboot you need to change the run-levels using the **chkconfig** utility. For example, if you want to run **sblim-sfc** in run-levels 3 and 5, use the following command:

```
#chkconfig sblim-sfc on --level 35
```

 **NOTE:** For more information on **chkconfig** and its usage, see the operating system documentation.

The managed system is configured and is ready to be used by the Server Administrator Web Server.

Winbind Configuration For openwsman And sfcfb For Red Hat Enterprise Linux Operating Systems

Follow the instructions mentioned below to configure openwsman and sfcfb on 32-bit OMI installation. In case of a 64-bit installation, replace with **.lib lib64**

1. Back up these files:

- /etc/pam.d/openwsman
- /etc/pam.d/sfcfb
- /etc/pam.d/system-auth

2. Replace the content of /etc/pam.d/openwsman and /etc/pam.d/sfcfb with

```
auth required pam_stack.so service=system-auth
auth required /lib/security/pam_nologin.so
account required pam_stack.so service=system-auth
```

3. Replace the content of /etc/pam.d/system-auth with

```
%PAM-1.0
This file is auto-generated.
User changes will be destroyed the next time authconfig is run.
auth required /lib/security/$ISA/pam_env.so
auth sufficient /lib/security/$ISA/pam_unix.so likeauth nullok
auth sufficient /lib/security/$ISA/pam_krb5.so use_first_pass
auth sufficient /lib/security/$ISA/pam_winbind.so use_first_pass
auth required /lib/security/$ISA/pam_deny.so
account required /lib/security/$ISA/pam_unix.so broken_shadow
account sufficient /lib/security/$ISA/pam_succeed_if.so uid 100 quiet
account [default=bad success=ok user_unknown= ignore] /lib/security/$ISA/
pam_krb5.so
account [default=bad success=ok user_unknown= ignore] /lib/security/$ISA/
pam_winbind.so
account required /lib/security/$ISA/pam_permit.so
password requisite /lib/security/$ISA/pam_cracklib.so retry=3
password sufficient /lib/security/$ISA/pam_unix.so nullok use_authtok md5
shadow
password sufficient /lib/security/$ISA/pam_krb5.so use_authtok
password sufficient /lib/security/$ISA/pam_winbind.so use_authtok
password required /lib/security/$ISA/pam_deny.so
session required /lib/security/$ISA/pam_limits.so
session required /lib/security/$ISA/pam_unix.so
session optional /lib/security/$ISA/pam_krb5.so
```

Workaround For The Libssl Issue

If the required library needed by **openwsman** is present on the system, the **autoconf_cim_component.sh** script tries to resolve the **libssl.so** issue. However, if the library is not present, then the script reports the same. Check if the latest version of the **libssl** library is installed on the system and then create a soft link with **libssl.so**.

For example: On a 32-bit installation, if you have **libssl.so.0.9.8a** and **libssl.so.0.9.8b** in **/usr/lib**, then create soft link with the latest **libssl.so.0.9.8b**:

- `ln -sf /usr/lib/libssl.so.0.9.8b /usr/lib/libssl.so`
- `ldconfig`

On a 64-bit installation, if you have `libssl.so.0.9.8a` and `libssl.so.0.9.8b` in `/usr/lib`, then create soft link with the latest `libssl.so.0.9.8b`:

- `ln -sf /usr/lib64/libssl.so.0.9.8b /usr/lib64/libssl.so`
- `ldconfig`

Winbind Configuration For openwsman And sfcf For SUSE Linux Enterprise Server Operating System

Follow the instructions mentioned below to configure openwsman and sfcf on 32-bit OMI installation. In case of a 64-bit installation, replace `.lib` with `.lib64`.

1. Back up the following files:
 - `/etc/pam.d/openwsman`
 - `/etc/pam.d/sfcf`
 - `/etc/pam.d/system-auth`
 - `/etc/pam.d/common-account`
2. Replace the content of `/etc/pam.d/openwsman/` and `/etc/pam.d/sfcf` with

```
%PAM-1.0
auth include common-auth
auth required /lib/security/pam_nologin.so
account include common-account
```
3. Replace the content of `/etc/pam.d/common-auth` with

```
auth required pam_env.so
auth sufficient pam_unix2.so debug
auth sufficient pam_winbind.so use_first_pass debug
```
4. Replace the content of `/etc/pam.d/common-account` with

```
account sufficient pam_unix2.so
account sufficient pam_winbind.so
```


Installing Managed System Software On Supported Linux And VMware ESX

The Systems Management installer supports both 32-bit and 64-bit architecture. The following table explains the operating system installation matrix for Systems Management.

Table 4. Operating System Installation Matrix

Operating System Architecture	32-bit Architecture	64-bit Architecture
Red Hat Enterprise Linux 6.5 64-bit	Not Supported	Install
Red Hat Enterprise Linux 5.9 32-bit	Install or Upgrade	Not supported
Red Hat Enterprise Linux 5.9 64-bit	Not supported	Install
SUSE Linux Enterprise Server (SLES) 11 SP 3 64-bit	Not supported	Install
ESX 4.1 U3 64-bit	Install	Not supported
ESXi 4.1 U3 64-bit	Not supported	Install
ESXi 5.1 U2 64-bit	Not supported	Install
ESXi 5.0 U3 64-bit	Not supported	Install
ESXi 5.5 64-bit	Not supported	Install

-  **NOTE:** On a Systems Management upgrade, it is recommended to upgrade to the latest open source components available on the DVD.
-  **NOTE:** If you are upgrading the operating system to a major version (from SLES 10 to SLES 11), uninstall the existing version of Systems Management and install the supported version.
-  **NOTE:** Before you migrate to a 64-bit version of Systems Management software, make sure to uninstall the 32-bit Systems Management and other OpenSource components (**openwsman-server**, **openwsman-client**, **libwsman1**, **sblim-sfcb**, **sblim-sfcc**, **libcmpiCpplmpl0**, **libsmbios2**, **smbios-utils-bin**) installed as part of the 32-bit Systems Management.
-  **NOTE:** The Inventory Collector RPM (**srvadmin-cm**) requires the following RPMs to be preinstalled on servers prior to 11G running supported 64-bit Linux operating system.
- glibc.i686
 - compat-libstdc++.i686
 - libstdc++.i686
 - zlib.i686libxml2.i686

If the dependent RPMs are not installed then Inventory Collector will not function as expected and exits with error messages.



NOTE: On systems running the Red Hat Enterprise Linux 5.9 (32-bit) operating system the Emulex driver is dependent on the following RPMs:

- kernel-headers-2.6.18-346.el5.i386.rpm
- glibc-headers-2.5-107.i386.rpm
- glibc-devel-2.5-107.i386.rpm
- gcc-4.1.2-54.el5.i386.rpm

If any of the RPMs listed above are missing, the system experiences issues in detecting the Emulex Network Adapters.

The installation scripts and RPM packages specific to supported Linux and VMware ESX operating systems are provided to install and uninstall the Server Administrator and other managed system software components. These installation scripts and RPMs are located in the **SYSMGMT/srvadmin/linux/supportscripts** directory available in the *Systems Management Tools and Documentation* DVD.

The install script **srvadmin-install.sh** allows silent or interactive installation. By including the **srvadmin-install.sh** script in the Linux scripts, install Server Administrator locally or across a network on single or multiple systems.

The second install method uses the Server Administrator RPM packages provided in the custom directories and the Linux **rpm** command. Write Linux scripts that install Server Administrator locally or across a network on single or multiple systems.

Using a combination of the two install methods is not recommended and may require that you manually install the required Server Administrator RPM packages provided in the custom directories, using the Linux **rpm** command.

For information on supported platforms and supported operating systems, see the *Systems Software Support Matrix*.

Software License Agreement

The software license for the Red Hat Enterprise Linux and SUSE Linux Enterprise Server version of the Systems Management software is located on the *Systems Management Tools and Documentation* DVD. Read the **license.txt** file. By installing or copying any of the files on the provided media, you are agreeing to the terms in this file. This file is also copied to the root of the software tree where you install the Systems Management software.

RPM For Individual Components

The following table lists the RPMs for individual components that can be used during installation:

Table 5. RPM for Individual Components

	Prerequisite	RPM	Service Names	Command Line Options for srvadmin-install.sh
Server Administrator Web Server	OS	srvadmin-omilcore srvadmin-omcommon srvadmin-jre srvadmin-omacs srvadmin-tomcat	dsm_om_connsvc	-w or --web

	Prerequisite	RPM	Service Names	Command Line Options for <code>srvadmin-install.sh</code>
Server Instrumentation	PE Server, OS	srvadmin-smcommon srvadmin-smweb srvadmin-omilcore srvadmin-smcommon srvadmin-omacore srvadmin-deng srvadmin-hapi srvadmin-isvc srvadmin-omcommon srvadmin-idrac-snmp srvadmin-isvc-snmp srvadmin-deng-snmp srvadmin-cm srvadmin-omacs srvadmin-ominst srvadmin-xmlsup srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_snmpd dsm_sa_shrsvcd	-d or --dellagent
Server Instrumentation Only	PE Server, OS	srvadmin-xmlsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-omcommon srvadmin-cm srvadmin-omacs srvadmin-ominst srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_shrsvcd	-g or --agent
SNMP	PE Server, OS	srvadmin-xmlsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-omcommon srvadmin-idrac-snmp	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_snmpd dsm_sa_shrsvcd	-m or --snmp

	Prerequisite	RPM	Service Names	Command Line Options for <code>srvadmin-install.sh</code>
		srvadmin-isvc-snmpp srvadmin-deng-snmpp srvadmin-cm srvadmin-omacs srvadmin-ominst srvadmin-rac-components		
CLI	PE Server, OS	srvadmin-xmldsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-omcommon srvadmin-omacore srvadmin-cm srvadmin-omacs srvadmin-ominst srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_shrsvcd	-i or --cli
OS Logging Option	PE Server, OS	srvadmin-xmldsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-omcommon srvadmin-oslog srvadmin-cm srvadmin-omacs srvadmin-ominst srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_shrsvcd	-l or --oslog
Remote Enablement	PE Server, OS, CIMOM, WSMAN CIMOM version >= SFCB 1.3.2 (applicable for systems running VMware ESX 4.0, Red Hat Enterprise Linux, and SUSE Linux) >= Open Pegasus 2.5.1-2	srvadmin-xmldsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-rac-components srvadmin-omacs srvadmin-ominst srvadmin-idrac-snmpp srvadmin-isvc-snmpp	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_snmpd dsm_sa_shrsvcd	-c or --cimagent

	Prerequisite	RPM	Service Names	Command Line Options for <code>srvadmin-install.sh</code>
	(applicable for systems running VMware ESX 3.5) WSMAN Version >= OpenWSMAN 2.1	srvadmin-deng-snmpp srvadmin-isvc srvadmin-omcommon srvadmin-omacore srvadmin-cm srvadmin-smcommon srvadmin-itunnelprovider		
Storage Agent and Server Instrumentation		srvadmin-xmlsup srvadmin-sysfsutils srvadmin-storelib-sysfs srvadmin-storelib srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-deng-snmpp srvadmin-isvc srvadmin-isvc-snmpp srvadmin-omcommon srvadmin-omacore srvadmin-omacs srvadmin-ominst srvadmin-cm srvadmin-realssd (applicable for x86_64 bit only) srvadmin-smcommon srvadmin-storage srvadmin-storage-cli srvadmin-idrac-snmpp srvadmin-storage-snmpp srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_snmpd dsm_sa_shrsvcd	-s or --storage
Remote Access SA Plugin Component -> Remote access	DRAC4 agent is installed if DRAC4 card is available in	srvadmin-xmlsup srvadmin-hapi srvadmin-argtable2	dsm_sa_datamgrd dsm_sa_eventmgrd	-r or --rac

	Prerequisite	RPM	Service Names	Command Line Options for <code>srvadmin-install.sh</code>
core components, Server Instrumentation	the server. DRAC5 agent is installed for 9G and 10G servers. iDRAC agent is installed for 11G and 12G servers with RAC presence.	srvadmin-omilcore srvadmin-deng srvadmin-deng-snmpp srvadmin-isvc srvadmin-isvc-snmpp srvadmin-omcommon srvadmin-omacs srvadmin-ominst srvadmin-omacore srvadmin-cm srvadmin-smcommon srvadmin-rac-components srvadmin-idracdrsc srvadmin-racdrsc srvadmin-idracadm7 srvadmin-idracadm srvadmin-racadm4 srvadmin-idrac7 srvadmin-idrac-snmpp srvadmin-idrac-vmcli	dsm_sa_snmpd dsm_sa_shrsvcd	
Storage Agent and Server Instrumentation	PE Server, OS	srvadmin-xmlsup srvadmin-hapi srvadmin-omacs srvadmin-ominst srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-cm srvadmin-rac-components	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_shrsvcd	-t or --stragent
Remote Enablement and Server Instrumentation	PE Server, OS	srvadmin-xmlsup srvadmin-hapi srvadmin-omilcore srvadmin-deng srvadmin-isvc srvadmin-cm srvadmin-omacs	dsm_sa_datamgrd dsm_sa_eventmgrd dsm_sa_shrsvcd	-z or --corecim

Prerequisite	RPM	Service Names	Command Line Options for <code>srvadmin-install.sh</code>
	srvadmin-ominst srvadmin- itunnelprovider srvadmin-rac- components		

 **NOTE:** To manage the server, select either Server Administrator Web Server or one of the Management Interfaces – CLI, SNMP or OS LOG along with Server Instrumentation (SI) or Server Administrator Storage Management Service (OMSS).

 **NOTE:** Command line options for [-t] and [-g] cannot be used without a management interface. These options need to be combined with management interface options such as [-w], [-i], [-z], [-l], or [-m]. For more information on custom installations, see [Server Administrator Custom Installation Utility](#).

OpenIPMI Device Driver

The Server Instrumentation feature of Server Administrator requires the OpenIPMI device driver that provides IPMI-based information and functionality.

All supported Linux systems contain the required version of IPMI module in the default kernel itself. You do not have to install the IPMI RPM. For more information on supported systems, see the *Systems Software Support Matrix*.

Degradation Of Functionality When The Server Administrator Instrumentation Service Is Started

After Server Administrator is installed, the Server Administrator Instrumentation Service performs a run-time check of the OpenIPMI device driver whenever it is started. The Server Administrator Instrumentation Service is started whenever you run either the **srvadmin-services.sh start** or **srvadmin-services.sh restart** commands, or when you restart the system (during which the Server Administrator Instrumentation Service is started.)

Server Administrator installation blocks the installation of Server Administrator packages if an appropriate version of the OpenIPMI device driver is not currently installed on the system. However, it is still possible, though not typical, that you can uninstall or replace a sufficient version of the OpenIPMI device driver after Server Administrator has been installed. Server Administrator cannot prevent this.

To account for a user uninstalling or replacing a sufficient version of the OpenIPMI device driver after Server Administrator has been installed, the Server Administrator Instrumentation Service checks the OpenIPMI device driver version whenever it is started. If a sufficient version of the OpenIPMI device driver is not found, the Server Administrator Instrumentation Service degrades itself so that it does not provide any of the IPMI-based information or functionality. Primarily, this means that it does not provide any probe data (for example, fans, temperatures, and voltage probe data.)

Installing Managed System Software

This section explains how to install managed system software using the following installation options:

- Using the **srvadmin-install.sh** shell script

 **NOTE:** If you have downloaded the managed system software installer (available as a **.tar.gz** file), the **srvadmin-install.sh** shell script is present as **setup.sh** in the root directory.

- Using the RPM command

Prerequisites For Installing Managed System Software

The prerequisites are:

- Log in as **root**.
- The running kernel must have loadable module support enabled.
- The **/opt** directory must have at least 250 MB of free space, and the **/tmp**, **/etc**, and **/var** directories must each have at least 20 MB of free space.
- Install the **ucd-snmp** or **net-snmp** package that is provided with the operating system if you use SNMP to manage the server. If you want to use supporting agents for the **ucd-snmp** or **net-snmp** agent, you must install the operating system support for the SNMP standard before you install Server Administrator. For more information about installing SNMP, see the installation instructions for the operating system you are running on the system.

 **NOTE:** When installing RPM packages, to avoid warnings concerning the RPM–GPG key, import the key with a command similar to `rpm --import <OM DVD mountpoint>/SYSMGMT/srvadmin/linux/RPM-GPG-KEY`

- In case of Red Hat Enterprise Linux 6.2 and above and SLES 11 SP2, install the **wsman** and **sblim** packages from the operating system DVD. See, [To install the wsman and sblim packages](#)
- Install all the prerequisite RPMs required for successful installation.
If the system had VMware ESX (version 4.0 or 4.1) factory-installed, Red Hat Enterprise Linux (versions 5.x and 6.0), or SUSE Linux Enterprise Server (version 10 and 11), see the [Dependent RPMs for Remote Enablement](#) section for information on any RPMs that you need to manually install prior to installing managed system software. Typically, you may not need to manually install any RPMs.

Installing The wsman And sblim Packages

1. In **Package selection**, select **Basic Server**.
2. Select **Customize now** and click **Next**.
3. Select **System Management** group.
4. From the sub-category, select **Web-based Enterprise Management** → **Optional Packages** option. The default selected packages are: **openwsman-client**, **sblim-sfcb**, **sblim-wbemcli**, and **wsmancli**. Deselect the **sblim-wbemcli** package from the above list.
5. Select **openwsman-server** and click **Next**.
6. After the operating system installation, install **libcmpiCpplImpl0** package from the operating system DVD or using the **Yum** utility.

Installing Managed System Software Using The Provided Media

The installer uses RPMs to install each component. The media (DVD) is divided into subdirectories to enable easy custom installation.

 **NOTE:** On the Red Hat Enterprise Linux 5.x operating system, DVDs are auto-mounted with the **-noexec** mount option. This option does not allow you to run any executable from the DVD. Manually mount the DVD and then run executables.

To review the software before you install it, follow this procedure:

1. Load the *Systems Management Tools and Documentation* DVD into the system's DVD drive.
2. Mount the DVD, if required.
3. When you have mounted the DVD, navigate to: **<OM DVD mount point>/SYSMGMT/srvadmin/linux/**
The installation script and RPM folder are available under the Linux directory.

Express Install

Use the provided shell script to perform the express installation on supported Linux and VMware ESX operating systems.

 **NOTE:** On the Red Hat Enterprise Linux 5.x operating system, DVDs are auto-mounted with the **-noexec** mount option. This option does not allow you to run any executable from the DVD. Manually mount the DVD and then run executables.

1. Log in as `root` to the system running the supported operating system where you want to install the managed system components.
2. Insert the *Systems Management Tools and Documentation* DVD into the DVD drive.
3. Mount the DVD, if required.
4. Navigate to **<OM DVD mount point>/SYSMGMT/srvadmin/linux/supportscripts** directory. Run the **srvadmin-install.sh** shell script, which performs an express installation.

```
sh srvadmin-install.sh --express
```

or

```
sh srvadmin-install.sh -x
```

The setup program installs the following managed system software features:

- Server Administrator Web Server
- Server Instrumentation
- Storage Management
- Remote Access Controller

Remote enablement is not installed and Server Administrator services do not start automatically.

 **NOTE:** The Inventory Collector RPM (**srvadmin-cm**) requires the following RPMs to be preinstalled on servers prior to 11G running supported 64-bit Linux operating system.

- glibc.i686
- compat-libstdc++.i686
- libstdc++.i686
- zlib.i686libxml2.i686

If the dependent RPMs are not installed then Inventory Collector will not function as expected and exits with error messages.

5. Start the Server Administrator services after the installation using the **srvadmin-services.sh** script by using the **sh srvadmin-services start** command.

Component Specific Install Using RPM Commands

The RPMs specific to a particular OpenManage component are grouped together. To facilitate an RPM-based installation, install the RPMs from the following directories:

- **SYSMGMT/srvadmin/linux/custom/<OS>/Remote-Enablement/< arch>**

- SYSMGMT/srvadmin/linux/custom/<OS>/SA-WebServer/<arch>
- SYSMGMT/srvadmin/linux/custom/<OS>/Server-Instrumentation/<arch>
- SYSMGMT/srvadmin/linux/custom/<OS>/add-RAC4/<arch>
- SYSMGMT/srvadmin/linux/custom/<OS>/add-RAC5/<arch>
- SYSMGMT/srvadmin/linux/custom/<OS>/add-StorageManagement/<arch>
- SYSMGMT/srvadmin/linux/custom/<OS>/add-iDRAC/<arch>

Where <OS> is the supported operating system and <arch> is 32-bit (i386) or 64-bit (x86_64).

 **NOTE:** In case of SUSE Linux Enterprise Server version 10 and 11: 32-bit rpm packages are provided for upgrade from the previous 32-bit installs only. If you do not have an existing installation, then you cannot install a 32-bit version of the software. You must install operating system specific rpms from the 64-bit directory.

For example, if you are running Red Hat Enterprise Linux version 5, you can customize the installation by adding the RPMs from the following directories:

Table 6. RPM Directory

Directory	RPM Package
SYSMGMT/srvadmin/linux/custom/ RHEL5/add-StorageManagement/<arch>	Storage Management component packages
SYSMGMT/srvadmin/linux/custom/ RHEL5/SAWebServer/<arch>	Server Administrator Web Server component packages
SYSMGMT/srvadmin/linux/custom/ RHEL5/Server-Instrumentation/<arch>	Server Instrumentation packages

The DVD provides RPMs that enable repository-based installation using clients such as Yum, Zypper, and Rug. There are RPMs that install the entire set or you can select individual RPMs to install specific components. The RPMs are available at:

SYSMGMT/srvadmin/linux/RPMS/supportRPMS/metaRPMS

The following list of RPMs enables the installation of a particular RPM set.

Table 7. Meta RPMs

Meta RPMs	Details
srvadmin-all	Installs all the components.
srvadmin-base	Installs the Server Instrumentation component. This component has to be installed before installing any of the other specific components.
srvadmin-idrac	Installs the iDRAC component.
srvadmin-rac4	Installs the DRAC 4 component.
srvadmin-rac5	Installs the DRAC 5 component.
srvadmin-standardAgent	Installs the Remote Enablement component.
srvadmin-storageservices	Installs the storage services component.
srvadmin-webserver	Installs the web server component.
srvadmin-server-snmp	Installs the server Simple Network Management Protocol (SNMP) component.

Meta RPMs	Details
<code>srvadmin-server-cli</code>	Installs the server Command Line Interface (CLI) component.
<code>srvadmin-storageservices-snmp</code>	Installs the storage SNMP component.
<code>srvadmin-storageservices-cli</code>	Installs the storage CLI component.

Related Links:

[Linux Installer Packages](#)

Custom RPMs Based Installation

The following is an example of custom RPMs-based installation of Server Administrator, including the installation of the Remote Enablement feature and the Storage Management Service components.

 **NOTE:** On the Red Hat Enterprise Linux 5.x operating system, DVDs are automounted with the `-noexec` mount option. This option does not allow you to run any executable from the DVD. You have to manually mount the DVD and then run executables.

1. Log in as `root` to the system running the supported operating system where you want to install the managed system components.
2. Insert the *Systems Management Tools and Documentation* DVD into the DVD drive.
3. Navigate to the operating system specific directory corresponding to the system.
4. Type the following command:

```
rpm -ivh Server-Instrumentation/<arch>/*.rpm
add-StorageManagement/<arch>/*.rpm
RemoteEnablement/<arch>/*.rpm
```

Server Administrator services do not start automatically.

 **NOTE:** Ensure that you install Server Instrumentation or Remote Enablement before installing Remote Access Controller or Storage Management.

 **NOTE:** If you choose to install the Remote Enablement feature, ensure that you install the dependent RPMs before installing this feature.

5. Start the Server Administrator services after the installation by using the command:

```
sh srvadmin-services start
```

 **NOTE:** You can install Server Administrator on any system that meets operating system dependencies. However, after installation, certain Server Administrator services may not be started on unsupported systems.

 **NOTE:** When Server Administrator is installed on a system, dependency issues related to RPMs may occur. To resolve these issues, install the missing RPMs from **SYSMGMT/srvadmin/linux/RPMS/supportRPMS/opensourcecomponents**. If the RPMs are not available in this directory, install these RPMs from the operating system media. If not available on the media, search for these RPMs on the Internet.

Related Links:

[Dependent RPMs for Remote Enablement](#)

Using The Shell Script To Perform The Custom Installation

You can run the Server Administrator Custom Install script in an interactive mode.

The basic usage of the script is:

```
srvadmin-install.sh [OPTION]...
```

Server Administrator Custom Installation Utility

The Server Administrator utility runs in an interactive mode if you do not specify any options, and runs silently if you provide one or more options.

The options are:

- **[-c|--cimagent]** — Installs Remote Enablement components.
- **[-d|--dellagent]** — Installs Server Instrumentation components. Including the granular components:
 - a. Server Administrator CLI Interface
 - b. Server Administrator SNMP Interface
 - c. Server Administrator Operating System Log Interface
- **[-g|--agent]** — Installs the Server Instrumentation agent only.*
- **[-h|--help]** — Displays the help text.
- **[-i|--cli]** — Installs Server Administrator Command Line Interface.*
- **[-l|--oslog]** — Installs operating system logging component.*
- **[-m|--snmp]** — Installs Server Administrator SNMP component.*
- **[-r|--rac]** — Installs applicable RAC components and Server Instrumentation components.
- **[-s|--storage]** — Installs Storage Management, Server Instrumentation, and Default Management Interfaces'.
- **[-t|--stragent]** — Installs Server Instrumentation and Storage Management. This requires at least one management interface option in combination.*
- **[-u|--update]** — Updates applicable Server Administrator components.
- **[-w|--web]** — Installs Server Administrator Web Server.
- **[-x|--express]** — Installs default components. Any other options passed will be ignored. The following components are installed::
 - a. Server Instrumentation
 - b. Storage Management
 - c. RAC, if applicable
 - d. Server Administrator Web Server
- **[-z|--corecim]** — Installs core CIM Interface.*

The following options can be used along with options stated above:

- **[-a|--autostart]** — Starts the installed services after components have been installed.
- **[-p|--preserve]** — Preserves the screen without clearing the installation information.



NOTE: If you do not use the **[-p | --preserve]** option during the installation, the history information on the screen gets erased.

* — Options included for Linux granular installation.

Using The Shell Script To Perform The Installation In Interactive Mode

This installation procedure uses the `srvadmin-install.sh` to prompt you for the installation of specific components.

1. Log in as `root` to the system running the supported operating system where you want to install the managed system components.
2. Insert the *Systems Management Tools and Documentation DVD* into the DVD drive.

3. Mount the DVD, if required.
4. Navigate to <OM DVD mount point>/SYSMGMT/srvadmin/linux/supportscripts.
5. Execute the script with the `sh srvadmin-install.sh` command and accept the terms of the end-user license agreement.
Executing the command displays a list of component options. If any of the components are already installed, then those components are listed separately with a check mark next to them. The Server Administrator installation options are displayed.
6. Press <c> to copy, <i> to install, <r> to reset and start over, or <q> to quit. If you press <c>, you are prompted to enter the absolute destination path.
When the installation is complete, the script has an option for starting the services.
7. Press <y> to start the services or <Enter> to exit.

Using The Install Script To Run In Silent Mode

Perform these steps for a silent installation using the `srvadmin-install.sh` shell script:

1. Log in as `root` to the system running the supported operating system where you want to install the managed system components.
2. Insert the *Systems Management Tools and Documentation* DVD into the DVD drive.
3. Mount the DVD, if required.
4. Navigate to <OM DVD mount point>/SYSMGMT/srvadmin/linux/supportscripts.
5. To install the Storage Management Service components, type the command `sh srvadmin-install.sh --storage` (long options) OR `sh srvadmin-install.sh -s` (short options)



NOTE: Long options can be combined with short options, and vice-versa.

6. Start Server Administrator services after the installation by typing the command `sh srvadmin-services start`.



NOTE: After installing Server Administrator, log out and then log in again to access the Server Administrator Command Line Interface (CLI).

Determining The Server Administrator Architecture

Use the following command to identify if the already installed Server Administrator is of 32-bit or 64-bit architecture

```
rpm -q --queryformat "%{NAME} - %{ARCH}\n" `rpm -qa | grep srvadmin`
```

The system displays a message identifying the architecture where, i386 refers to 32-bit and x86_64 refers to 64-bit.

Managed System Software Installation Using Third Party Deployment Software

You can use third-party deployment software, such as Altiris Deployment Solution, VMWare Update Manager (VUM), or Linux Respository for Yellowdog Updater Modified (YUM), Rug, and Zypper, to install managed systems software on supported systems.

To distribute and install Server Administrator using Altiris Deployment Solution:

1. Start the Altiris application
2. Import **OpenManage_Jobs.bin** located at `SYSMGMT\srvadmin\support\Altiris` on the *Systems Management Tools and Documentation* DVD
3. Specify a job folder to import **OpenManage_Jobs.bin**.
4. Modify the **Run Script** and **Copy File** tasks to match the deployment environment.

5. Schedule the job to run on the supported systems that are managed from the Altiris Deployment Solution.

 **NOTE:** For more information on VMWare Update Manager, see [Using the VMWare Update Manager \(VUM\)](#).

Linux Repository

The Linux Repository is the official repository for all related software and updates for your Linux systems. You can use this repository to complete the following tasks:

- Install Server Administrator
- Install drivers for all your Linux systems
- Install BIOS and firmware updates

Setting Up The Linux Repository

Before you can start using the Linux Repository for installing software or upgrades, you must set up the repository. For more information, see <http://linux.dell.com/repo/hardware/>.

Set up the repository with:

```
wget -q -O - http://linux.dell.com/repo/hardware/latest/bootstrap.cgi | bash
```

 **NOTE:** If you require 64-bit packages, uninstall the existing 32-bit packages before installing the new software. Server Administrator is designed to match your current operating system.

Installation Using Linux Repository

You can install Server Administrator using the Linux Repository by following any of the methods listed below:

 **NOTE:** Ensure that you set up the Linux Repository before you install the software from the repository.

 **NOTE:** Server Administrator will not install on unsupported systems. If you try installing Server Administrator on unsupported systems, you will receive a message that the system is not supported and the installation will fail.

Using YUM

 **NOTE:** Ensure that you are using the latest version of YUM as the older versions do not support plug-ins or mirrorlists.

If you are using YUM with CentOS, or Scientific Linux, ensure that the plug-ins are enabled as the system connects to a system specific repository using a YUM plug-in. If the plug-in is not enabled, the repository will not work properly and you will not be able to install packages from the repository. Add the `plugins=1` line, to your **yum.conf**, if the plug-in is not enabled.

The following command line will work for Red Hat Enterprise Linux 5 and 6, CentOS, and Scientific Linux:

```
yum install srvadmin-all
```

After the installation, type the following command to start the Server Administrator services:

```
srvadmin-services start
```

 **NOTE:** You can install YUM as an add-on for SLES 9 or 10.

Using RUG

You can install Server Administrator using `rug` for SLES 10 or higher.

```
rug install srvadmin-base
rug install srvadmin-webserver
rug install srvadmin-storageservices
```



NOTE: You must have **setserial** installed, if you want to install **srvadmin-all**.

Using ZYPPE

You can install Server Administrator using `zypper` for SLES 11 or higher.

```
zypper install srvadmin-all
```

Uninstalling Managed System Software

To uninstall Managed System Software, log in as `root`.

Uninstalling Managed System Software Using The Uninstall Script

An uninstallation script is installed when you install Server Administrator. Execute the script by typing `srvadmin-uninstall.sh` and then pressing <Enter>.

Uninstalling Managed System Software Using The RPM Command

The individual components of systems management software can be uninstalled without uninstalling all of systems management.

To uninstall only the Server Administrator Web Server, use the command `rpm -e `rpm -qa | grep srvadmin-tomcat``.

During an uninstallation, files in which user settings are made are preserved with the **.rpmsave** file extension. Log files are also preserved after the uninstallation.

Installing Systems Management Software On VMware ESXi

VMware ESXi is factory-installed on some systems. For a list of these systems, see the latest *Systems Software Support Matrix*. Use Server Administrator Web Server version 7.0 to access VMware ESXi 4.0 U3, VMware ESXi 4.1 U2, VMware ESXi 5.0 U1 systems.

Server Administrator is available as a .zip file for installing on systems running VMware ESXi. The **zip** file, **OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i_<bld-revno>.zip**, where <version> is the supported ESXi version.

Download VMware vSphere Command Line Interface (vSphere CLI) from **vmware.com** and install on the Microsoft Windows or Linux system. Alternately, you can import VMware vSphere Management Assistant (vMA) to the ESXi host.

Using The vSphere CLI

To install systems management software on VMware ESXi using the vSphere CLI:

1. Copy and unzip the **OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i_<bld-revno>.zip** file to a directory on the system. For ESXi 5.0 and ESXi 5.0 P1, copy the unzipped file to the **/var/log/vmware** folder on the ESXi 5.0 U1 server.

 **NOTE:** For ESX 4.x, you do not have to unzip the file.
2. Shut down all guest operating systems on the ESXi host and put the ESXi host in maintenance mode.
3. If you are using vSphere CLI on Windows, navigate to the directory where you have installed the vSphere CLI utilities.

If you are using vSphere CLI on Linux, execute the command from any directory.
4. Execute the following command:

For VMware ESXi 4.0/ESXi 4.1: `vihostupdate.pl --server<IP address of ESXi host>-i -b <path to Dell OpenManage file>`

For VMware ESXi 5.0 U1: `esxcli --server <IP Address of ESXi 5.0 host> software vib install -d /var/log/vmware/<Dell OpenManage file>`

 **NOTE:** The .pl extension is not required if you are using vSphere CLI on Linux.
5. Enter the root username and password of the ESXi host when prompted.

The command output displays a successful or a failed update.
6. Restart the ESXi host system.

To get or list the information about the installed VIBs:

- For ESXi 4.x, use `vihostupdate.pl --server <IP> --query` or `-q`
- For ESXi 5.x, use `esxcli --server <IP>software vib get` or `software vib list`

The VIB contains the following items:

- Server Administrator Instrumentation Service
- Remote Enablement
- Server Administrator Storage Management
- Remote Access Controller

Related Links:

[Troubleshooting](#)

Using The VMware vSphere Management Assistant (vMA)

The vMA allows administrators and developers to run scripts and agents to manage ESX/ESXi systems. For more information on vMA, see vmware.com/support/developer/vima/.

1. Log on to vMA as an administrator and provide the password when prompted.
2. Copy and unzip the **OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i_<bld-revno>.zip** file to a directory on the vMA.
3. Shut down all guest operating systems on the ESXi host and put the ESXi host in maintenance mode.
4. In vMA, execute the following command:
 For VMware ESXi 4.0/ESXi 4.1: `vihostupdate --server <IP address of ESXi Host> -i -b <path to Dell OpenManage file>`
 For VMware ESXi 5.0 U1: `esxcli --server <IP Address of ESXi 5.0 host> software vib install -d /var/log/vmware/<Dell OpenManage file>`
5. Enter the root username and password of the ESXi host when prompted.
 The command output displays a successful or a failed update.
6. Restart the ESXi host system.

When you run the command, the following components are installed on the system:

- Server Administrator Instrumentation Service
- Remote Enablement
- Server Administrator Storage Management
- Remote Access Controller

Install the Server Administrator Web Server separately on a management station.

After installing Server Administrator, enable the Server Administrator Services.

Related Links:

- [Troubleshooting](#)
- [Enabling Server Administrator Services on the Managed System](#)

Using The VMware Update Manager (VUM)

To install Server Administrator using VUM:

1. Install VMware vSphere 5.x (vCenter Server, vSphere Client, and VMware vSphere Update Manager) on a system running the Windows Server 2008 R2 SP1 (64-bit) operating system.
2. On the desktop, double-click **VMware vSphere Client** and login to vCenter Server.
3. Right-click **vSphere Client host** and click **New Datacenter**.
4. Right-click **New Datacenter** and click **Add Host**. Provide information for the ESXi server per online instructions.

5. Right-click the ESXi host added in the previous step and click **Maintenance Mode**.
6. From **Plug-ins** select **Manage Plug-ins** → **download VMware Update Manager** (The status is enabled if the download is successful.) Follow the instructions to install the VUM client.
7. Select the ESXi host. Click **Update Manager** → **Admin view** → **Patch Repository** → **Import Patches** and follow the online instructions to upload the patch successfully.
The offline bundle is displayed.
8. Click **Baselines and Groups**.
9. Click **create** from Baselines tab, mention baseline name and select **Host Extension** as baseline type. Complete the rest as per instructions.
10. Click **Admin View**.
11. Click **Add to Baseline** (against the uploaded patch name) and select the baseline name that you have created in step 8.
12. Click **Compliance view**. Select the **Update Manager** tab. Click **Attach** and select the Extension Baseline created in step 8 and follow the instructions.
13. Click **Scan** and select **Patches & Extensions** (if not selected by default) and click on **Scan**.
14. Click **Stage**, select **created Host Extension** and follow the instructions.
15. Click **Remediate** and follow the instructions once the staging is completed.
Server Administrator installation is complete.
16. Reboot the host.

 **NOTE:** For more information on VMware Update Manager, see the VMware official website.

 **NOTE:** You can install Server Administrator from the VUM repository, <https://vmwaredepot.dell.com/>.

Using The Power CLI

To install Server Administrator using Power CLI:

1. Install the supported PowerCLI of ESXi on a supported Windows system.
2. Copy the **OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i_<bld-revno>.zip** file to the ESXi host.
3. Navigate to the bin directory.
4. Run **Connect-VIServer** and provide the server and other credentials.
5. Log on to the ESXi host using supported vSphere CLI of ESXi 5.0 U1 and create a datastore.
6. Create a folder **OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i** on ESXi 5.0 U1 host under **/vmfs/volumes/<datastore_name>** directory.
7. Copy the ESXi zip file on ESXi 5.0 U1 host to **/vmfs/volumes/<datastore_name>OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i** directory.
8. Unzip the zip file in the above specified directory.
9. Run the following command in Power CLI **Install-VMHostPatch -VMHost 10.94.171.97 -HostPath /vmfs/volumes/<datastore_name>name/OMSrvAdmin- Dell-Web-<version>-<build ID>.VIBESX<version>i/ cross_oem-dell-openmanage-esxi_<version>-0000-metadata.zip**
10. Reboot the ESXi host.

11. Run the following command to check if OpenManage is installed successfully on the host. `esxcli software vib list|grep -i open`
OpenManage is displayed.

 **NOTE:** For more information on Power CLI, see the VMware official website.

Accessing Server Administrator on VMware ESXi

To manage Server Administrator on VMware ESXi using the Server Administrator Web Server interface:

1. Install only the Server Administrator Web Server interface on another system.
 **NOTE:** Ensure that the version of the Server Administrator Web Server interface is greater or equal to the version of the Server Instrumentation installed.
2. Run the Server Administrator Web Server interface.
The **Managed System Login** screen is displayed.
3. On the **Managed System Login** screen, type the following credentials of the VMware ESXi system you want to access, and then click **Submit**.
 - **Hotname / IP address:** — Is the hostname or IP address of the management station. Type the hostname or IP address in the format Hostname:Port Number, or IP address:Port Number.
 - **Username:**
 - **Password:**

The Server Administrator screen is displayed.

Enabling Server Administrator Services On The Managed System

The Server Administrator Web Server communicates with the VMware ESXi system through the Server Administrator Common Interface Model (CIM) provider. The Server Administrator CIM provider is an Original Equipment Manufacturer (OEM) provider on the VMware ESXi system. CIM OEM providers are disabled by default on VMware ESXi 4.0 and ESXi 4.1. Enable the CIM OEM providers on the VMware ESXi system before accessing it using Server Administrator Web Server.

 **NOTE:** In ESXi 4.1 U2, ESXi 5.0 U1 CIM OEM provider is enabled by default.

Enabling CIM OEM Providers Using vSphere Client (For VMware ESXi 4.0/ESXi 4.1)

To enable CIM OEM providers using VMware vSphere Client, you must have the vSphere Client tool installed. You can download and install the tool from https://<IP_address of ESXi host> where <ip_address> is the IP address of the VMware ESXi system.

To enable CIM OEM providers on the VMware ESXi system using vSphere Client:

1. Log on to the VMware ESXi host system using vSphere Client.
2. Click the **Configuration** tab.
3. Under the **Software** section on the left side, click **Advanced Settings**.
4. In the **Advanced Settings** dialog box, click **UserVars** on the left pane.
5. Change the value of the **CIMOEMProvidersEnabled** (for ESXi 4.0) or **CIMoemProviderEnabled** (for ESXi 4.1) field to **1**.

6. Click **OK**.
7. For the changes to take effect without restarting the system, use the **Restart Management Agents** option in the Direct Console User Interface (DCUI) on the local console of the VMware ESXi system.

 **NOTE:** This option is available under **Troubleshooting Options** in ESXi 4.1.

If the changes are not effective and you cannot connect to the VMware ESXi host using Server Administrator, restart the VMware ESXi host system.

Enabling CIM OEM Providers Using vSphere CLI (For VMware ESXi 4.0/ESXi 4.1)

To enable CIM OEM providers on the VMware ESXi system using vSphere CLI:

1. If you are using vSphere CLI on Windows, navigate to the directory where you have installed the vSphere CLI utilities. On Linux, proceed to step 2.
2. Execute the command `vicfg-advcfg.pl --server <ip_address of ESXi host> --username <user_name> --password <password> --set 1 UserVars.CIMOEMProvidersEnabled`

 **NOTE:** For ESXi 4.0, use **CIMOEMProvidersEnabled** and for ESXi 4.1, use **CIMoemProviderEnabled**.

The **.pl** extension is not required if you are using vSphere CLI on Linux.

3. For the changes to take effect without restarting the system, use the **Restart Management Agents** option in the DCUI on the local console of the VMware ESXi system.

 **NOTE:** This option is available under **Troubleshooting Options** in ESXi 4.1.

If the changes are not effective and you cannot connect to the VMware ESXi host using Server Administrator, restart the VMware ESXi host system.

Enabling CIM OEM Providers Using vMA (For VMware ESXi 4.0/ESXi 4.1)

To enable CIM OEM providers on the VMware ESXi system using vMA:

1. Log in to the vMA as an administrator and provide the password when prompted.
2. Execute the command `vicfg-advcfg --server <ip_address of ESXi host> --username <user_name> --password <password> --set 1 UserVars.CIMOEMProvidersEnabled`

 **NOTE:** For ESXi 4.0, use **CIMOEMProvidersEnabled** and for ESXi 4.1, use **CIMoemProviderEnabled**.

3. For the changes to take effect without restarting the system, use the **Restart Management Agents** option in the DCUI on the local console of the VMware ESXi system.

If the changes are not effective and you cannot connect to the VMware ESXi host using Server Administrator, restart the VMware ESXi host system.

Uninstalling The Existing Systems Management VIB

To uninstall the existing Systems Management VIB:

1. Run the following command to uninstall the VIB:

On ESXi 4.x: `vihostupdate.pl --server <IP> -r -B <VIB Name>`

On ESXi 5.x: `esxcli --server <IP> software vib remove <VIB Name>`

2. Reboot the system after uninstalling.

Configuring The SNMP Agent On Systems Running VMware ESXi

Server Administrator generates Simple Network Management Protocol (SNMP) traps in response to changes in the status of sensors and other monitored parameters. You must configure one or more trap destinations on the system running Server Administrator to send SNMP traps to a management station. Server Administrator supports SNMP traps on VMware ESXi but does not support SNMP Get and Set operations because VMware ESXi does not provide the required SNMP support. You can use the VMware vSphere CLI to configure VMware ESXi to send SNMP traps to a management application.

 **NOTE:** For more information about using the VMware vSphere CLI, see the VMware support site at vmware.com/support.

Configuring The System To Send Traps To A Management Station Using The vSphere CLI

Server Administrator generates SNMP traps in response to changes in the status of sensors and other monitored parameters. One or more trap destinations must be configured on the system running Server Administrator to send SNMP traps to a management station.

Configure the ESXi system running Server Administrator to send traps to a management station:

1. Install the VMware vSphere CLI.
2. Open a command prompt on the system in which the vSphere CLI is installed.
3. Navigate to the directory in which the vSphere CLI is installed. The default location on Linux is `/usr/bin` and on Windows is `C:\Program Files\VMware\VMware vSphere CLI\bin`.
4. Configure the SNMP setting using the command: `vicfg-snmp.pl --server <server> --username <username> --password <password> -c <community> -t <hostname>@162/<community>`

where `<server>` is the hostname or IP address of the ESXi system, `<username>` is a user on the ESXi system, `<password>` is the password of the ESXi user, `<community>` is the SNMP community name and `<hostname>` is the hostname or IP address of the management station.

 **NOTE:** If you do not specify a user name and password, you are prompted to specify the same.

5. Enable SNMP using the command: `vicfg-snmp.pl --server <server> --username <username> --password <password> -E`
6. View the SNMP configuration using the command: `vicfg-snmp.pl --server <server> --username <username> --password <password> -s`

7. Test the SNMP configuration using the command: `vicfg-snmp.pl --server <server> --username <username> --password <password> -T`



NOTE: The `.pl` extension is not required if you are using vSphere CLI on Linux or using vMA.

The SNMP trap configuration takes effect immediately without restarting any services.

Troubleshooting

- **When attempting to use the `vihostupdate` command, the following error may be displayed:**

```
unpacking c:\OM-SrvAdmin-Dell-Web-<version>-<bldno>.VIB-ESX<version>i_<bld-  
revno>.zip  
metadata.zip.sig does not exist  
signature mismatch : metadata.zip  
Unable to unpack update package.
```

This error is displayed if you are using an older version of the Remote CLI. To resolve this issue, download and install the latest vSphere version of the CLI.

- **When attempting to use the `vihostupdate` command, the following error may be displayed:**

```
Unable to create, write or read a file as expected.I/O Error (28) on file :  
[Errno 28] No space left on device.
```

See the VMware KB article 1012640 at kb.vmware.com to fix this error.

Frequently Asked Questions

What ports do systems management applications use?

The default port used by Server Administrator is 1311. These ports are configurable. For port information of a particular component, see the User Guide of that respective component.

When I run virtual media on the DRAC controller over a Wide Area Network (WAN) with low bandwidth and latency, launching Systems Management Install directly on the virtual media failed, what do I do?

Copy the web install package to the local system and then launch systems management Install.

Do I need to uninstall the Adaptec Fast Console application installed on the system before installing the Server Administrator Storage Management Service?

Yes, if you already have Adaptec Fast Console installed on the system, you must uninstall this application before installing the Server Administrator Storage Management Service.

Red Hat Enterprise Linux or SUSE Linux Enterprise Server

After installing Server Administrator, I cannot log in.

Log out and then log in again to access the Server Administrator Command Line Interface (CLI).

I see the following message when I try to install Server Administrator on a guest Linux operating system.

```
./srvadmin-install.sh: line 2295 : [: ==: unary operator expected.
```

When installing Systems Management components on a guest Linux operating system, the warning message may be displayed. However, the installation continues and completes without any loss of functionality.

I manually installed my Red Hat Enterprise Linux 4 64-bit operating system and can see RPM dependencies while installing Server Administrator. Where can I find these dependent RPM files?

For Red Hat Enterprise Linux, the dependent RPM files are on the Red Hat Enterprise Linux installation media. All other RPMs are available in the `/SYSMGMT/srvadmin/linux/RPMS/supportRPMS\opensource-components` directory. To install or update all the dependent RPM files execute the following command:

```
rpm -ivh /SYSMGMT/srvadmin/linux/RPMS/ supportRPMS/opensource-components
```

You can then continue with the Server Administrator installation.

I have performed a non-default install of the Linux operating system using the Linux operating system media, I see missing RPM file dependencies while installing Server Administrator?

Server Administrator is a 32-bit application. When installed on a system running a 64-bit version of Red Hat Enterprise Linux operating system, the Server Administrator remains a 32-bit application, while the device drivers installed by Server Administrator are 64-bit. If you attempt to install Server Administrator on Red Hat Enterprise Linux (versions 5 and version 6) for Intel EM64T, ensure that you install the applicable 32-bit versions of the missing RPM file dependencies. The 32-bit RPM versions always have **i386** in the filename extension. You may also experience failed shared object files (files with `so` in the filename extension) dependencies. In this case, you can determine which RPM is needed to install the shared object, by using the RPM `--whatprovides` switch. For example: `rpm -q --whatprovides libpam.so.0`

An RPM name such as **pam-0.75-64** could be returned, so obtain and install the **pam-0.75-64.i386.rpm**. When Server Administrator is installed on a system running a 64-bit version of Linux operating system, ensure that the **compat-libstdc++-<version>.i386.rpm** RPM package is installed. You need to resolve the dependencies manually by installing the missing RPM files from the Linux operating system media.

 **NOTE:** If you are using later versions of supported Linux operating systems and the RPM files available in the directory **SYSMGMT/srvadmin/linux/RPMS/supportRPMS** on the DVD are incompatible, use the latest RPMs from the operating system media.

Where can I find the source packages for Open Source RPMs?

Source packages for Open Source RPMs are available on an orderable DVD image.

What do I do when management station RAC utility installation fails due to missing RPM file?

During the installation of the management station RAC utility (`mgmtst-racadm` RPM under `/SYSMGMT/ManagementStation/linux/rac` directory on the *Systems Management Tools and Documentation* DVD), the installation may fail due to missing RPM file dependencies on **libstdc++.so** libraries. Install the **compat-libstdc++** RPM provided in the same directory to resolve the dependency and retry the installation.

When using the `rpm -e 'rpm -qa | grep srvadmin'` command to remove systems management software, some RPM utility versions may schedule an uninstallation in an incorrect order, which results in users encountering misleading warning or error messages. What is the solution?

The solution is to use the systems management uninstall script `srvadmin-uninstall.sh`, provided on the DVD.

What do I do when I am asked to authenticate using the root user account?

Systems Build and Update Utility adds a script to the root user's `.bash_profile` file that prompts for the installation of systems management software. This script may interfere with remote client applications that authenticate using the root user account on the system, but do not have a means to handle user prompts. To remedy this limitation, edit the `.bash_profile` file and comment the line `[ ${SHLVL} ] . . .`.

During uninstallation, error: `%preun(srvadmin-NAME-X.Y.Z-N.i386) scriptlet failed, exit status 1` error message is displayed.

There may be problems uninstalling Server Administrator after an unsuccessful upgrade during a manual RPM upgrade. The following error message is displayed:

```
error: %preun(srvadmin-NAME-X.Y.Z-N.i386) scriptlet failed, exit status 1
```

In this case, `NAME` is a feature name, for example `omacore`. `X.Y.Z-N` is the version and build number of the feature. Some possible solutions to rectify this problem:

1. Attempt to uninstall again. For example, use the following command:

```
rpm -e srvadmin-NAME-X.Y.Z-N.i386
```
2. Delete the `upgrade.relocation=bad` line if present in the `/etc/omreg.cfg` file and attempt to uninstall again.

Why am I getting a warning concerning the RPM package key during installation?

The RPM files are signed with a digital signature. To avoid this warning, you should mount the media or package, and import the key using a command such as the following:

```
rpm --import /mnt/dvdrom/SYSMGMT/srvadmin/linux/RPM-GPG-KEY
```

What are the names of all the Systems Management features under Red Hat Enterprise Linux or SUSE Linux Enterprise Server?

The following table lists the names of all systems management features and their corresponding init script names under Red Hat Enterprise Linux and SUSE Linux Enterprise Server operating systems.

Table 8. Systems Management Features — VMware ESX, Red Hat Enterprise Linux, and SUSE Linux Enterprise Server

Feature	Name in VMware ESX, Red Hat Enterprise Linux, and SUSE Linux Enterprise Server
Managed System Services Feature	Feature init Script Name
DSM SA Device Drivers	instsvcdrv
DSM SA Data Engine Service	dataeng

Feature	Name in VMware ESX, Red Hat Enterprise Linux, and SUSE Linux Enterprise Server
DSM SA Shared Service	dsm_om_shrsvc
DSM SA Connection Service	dsm_om_connsvc
DSM SM LSI Manager	mptctl
Integrated Remote Access Controller (iDRAC)	None
Remote Access Controller (DRAC 4)	racsvc
Remote Access Controller (DRAC 5)	None

What do the directories under `srvadmin/linux/custom/<operating system>` contain?

The following table lists the names of the directories in the `SYSMGMT/srvadmin/linux/custom/<operating system>` directory.

Table 9. Names of the Directories Under the `srvadmin/linux/custom/<operating system>` directory

Name of RPM	Description	Other Server Administrator RPMs required
Server-Instrumentation — This is the core code for Server Administrator. It provides motherboard alerts and contains the CLI that allows to monitor and control Server Administrator, for example, <code>omconfig</code> , <code>omdiag</code> , and <code>omreport</code> . All peripheral packages, except the standalone DRAC support, require all or most of the RPMs in this directory to be installed.		
<code>srvadmin-cm</code>	Server Administrator Inventory Collector — Systems management change management inventory collector.	<code>srvadmin-omilcore</code> , <code>srvadmin-deng</code> , and <code>srvadmin-omacore</code>
<code>srvadmin-deng</code>	Server Administrator Data Engine — Systems management provides a data management framework for systems management software.	<code>srvadmin-omilcore</code>
<code>srvadmin-hapi</code>	Server Administrator Hardware Application Programming Interface — This systems management package provides the device drivers and libraries needed by systems management software to access information about the hardware on supported systems.	<code>srvadmin-omilcore</code>
<code>srvadmin-isvc</code>	Server Administrator Instrumentation Service — Server Administrator provides a suite of systems management	<code>srvadmin-omilcore</code> , <code>srvadmin-deng</code> , and <code>srvadmin-hapi</code>



NOTE: You may need to install IPMI drivers for proper functionality.

Name of RPM	Description	Other Server Administrator RPMs required
	information for keeping supported systems on the network healthy. Server Administrator Instrumentation Service provides fault management information, prefailure information, and asset and inventory information to management applications. The Instrumentation Service monitors the health of the system and provides rapid access to detailed fault and performance information about the hardware on supported systems. The Instrumentation Service requires installation of systems management device drivers.	
srvadmin-omacore	Server Administrator — Systems management managed mode core and CLI.	srvadmin-omilcore and srvadmin-deng
srvadmin-omhip	Server Administrator Instrumentation Service Integration Layer — Provides Instrumentation CLI.	srvadmin-omilcore, srvadmin-deng, srvadmin-hapi, srvadmin-iscv, and srvadmin-omacore
srvadmin-omilcore	Server Administrator Install Core — This is the core install package that provides the tools necessary for the rest of the Systems management install packages. All Server Administrator RPMs require this RPM.	
srvadmin-syscheck	Package that checks the level of systems management support.	srvadmin-omilcore
add-iDRAC — Software for remote management of third-generation Remote Access Controllers. For example, iDRAC.		
srvadmin-idrac-components	Integrated Remote Access Card Data Populator Remote Access Controller components.	srvadmin-omilcore, srvadmin-deng, srvadmin-hapi, and srvadmin-racser
srvadmin-idracadm	iDRAC Command Interface — The command-line user interface to the Integrated Remote Access Controller.	srvadmin-omilcore

Name of RPM	Description	Other Server Administrator RPMs required
srvadmin-idracdrsc	iDRAC Integration Layer — Integrated Remote Access CLI and Web Plug-in to Server Administrator.	srvadmin-omilcore, srvadmin-deng, srvadmin-rac4 components, and srvadmin-omacore
add-RAC4 — Software for remote management of fourth-generation Remote Access Controllers. For example, DRAC 4.		
srvadmin-rac4-components	Remote Access Card Data Populator — Remote Access Controller components.	srvadmin-omilcore, srvadmin-deng, srvadmin-hapi, and srvadmin-racsvc
srvadmin-racadm4	RAC Command Interface — The command-line user interface to the Remote Access Controller (RAC).	srvadmin-omilcore
srvadmin-racdrsc4	DRAC 4 Integration Layer — Remote Access CLI and Web Plugin to Server Administrator.	srvadmin-omilcore, srvadmin-deng, srvadmin-rac4 components, and srvadmin-omacore
srvadmin-racsvc	Remote Access Card Managed Node — Remote Access Controller (RAC) services supporting the central administration of server clusters and the remote administration of distributed resources.	srvadmin-omilcore
add-RAC5 — Software for remote management of fifth generation Remote Access Controllers. For example, DRAC 5.		
srvadmin-rac5-components	Remote Access Card Data Populator, DRAC 5 and Remote Access Controller components, DRAC 5.	srvadmin-omilcore, srvadmin-deng, and srvadmin-hapi
srvadmin-racadm5	RAC Command Interface — The command-line user interface to the Remote Access Controller (RAC).	srvadmin-omilcore and srvadmin-hapi
srvadmin-racdrsc5	DRAC 5 Integration Layer — Remote Access CLI and Web Plug-in to Server Administrator.	srvadmin-omilcore, srvadmin-deng, srvadmin-omacore, and srvadmin-rac5 components
add-StorageManagement — Storage Management RAID configuration utility and storage alert software.		
srvadmin-storage	Storage Management — Provides Systems Management Storage Services.	srvadmin-omilcore, srvadmin-deng, and srvadmin-omacore
SA-WebServer — Provides web access to manage the server.		

Name of RPM	Description	Other Server Administrator RPMs required
srvadmin-hapi	Server Administrator Hardware Application Programming Interface — This systems management package provides the device drivers and libraries needed by systems management software to access information about the hardware on supported systems.	srvadmin-omilcore
srvadmin-tomcat	Secure Port Server — Systems Management Managed Node Web Server package.	srvadmin-omilcore, srvadmin-deng, srvadmin-omacore, and srvadmin-jre
srvadmin-jre	Server Administrator Sun Java Runtime Environment — Systems management managed node Java runtime.	srvadmin-omilcore, srvadmin-deng, and srvadmin-omacore
srvadmin-omauth	Provides the authentication files.	srvadmin-omilcore
srvadmin-omcommon	Provides the common framework required by Server Administrator.	srvadmin-omilcore
srvadmin-omilcore	Server Administrator Web Server Install Core — This is the core install package. All Server Administrator Web Server RPMs require this RPM.	
srvadmin-wsmanclient	Operating system-specific WSMAN client package.	srvadmin-omcommon and srvadmin-omauth
Remote-Enablement — Manage and monitor the current system using some other remote system.		
srvadmin-cm	Server Administrator Inventory Collector — Systems management change management inventory collector.	srvadmin-omilcore, srvadmin-deng, and srvadmin-omacore
srvadmin-deng	Server Administrator Data Engine — Systems management provides a data management framework for systems management software.	srvadmin-omilcore
srvadmin-hapi	Server Administrator Hardware Application Programming Interface — This systems management package provides the device drivers and libraries needed by systems management software to access information	srvadmin-omilcore

Name of RPM	Description	Other Server Administrator RPMs required
	about the hardware on supported systems.	
srvadmin-isvc	Server Administrator Instrumentation Service — Server Administrator provides a suite of systems management information for keeping supported systems on the network healthy. Server Administrator Instrumentation Service provides fault management information, prefailure information, and asset and inventory information to management applications. The Instrumentation Service monitors the health of the system and provides rapid access to detailed fault and performance information about the hardware on supported systems. The Instrumentation Service requires installation of systems management device drivers.	srvadmin-omilcore, srvadmin-deng, and srvadmin-hapi
srvadmin-omacore	Server Administrator — Systems management managed mode core and CLI.	srvadmin-omilcore and srvadmin-deng
srvadmin-omcommon	Provides Common Framework required by Server Administrator.	srvadmin-omilcore
srvadmin-omhip	Server Administrator Instrumentation Service Integration Layer — Provides Instrumentation CLI.	srvadmin-omilcore, srvadmin-deng, srvadmin-hapi, srvadmin-isvc, and srvadmin-omacore
srvadmin-omilcore	Server Administrator Install Core — This is the core install package that provides the tools necessary for the rest of the Systems management install packages. All Server Administrator RPMs require this RPM.	
srvadmin-ssa	Enables management of the system from a remote system on which Server Administrator Web Server is installed, using WS-Man interfaces.	srvadmin-omacore, srvadmin-omhip, and srvadmin-isvc.

Name of RPM	Description	Other Server Administrator RPMs required
srvadmin-syscheck	Package that checks the level of systems management support.	srvadmin-omilcore

What are the additional components that can be installed on a system that already has Server Administrator installed?

There are a few additional components that can be installed on a system that already has Server Administrator installed. For example, you can install Online Diagnostics on a system that has previously been installed with managed system software. On such a system, while uninstalling Server Administrator, only those RPM packages that are not required by any of the newly installed components are uninstalled. In the above example, Online Diagnostics requires packages such as - **srvadmin-omilcore-X.Y.Z-N** and **srvadmin-hapi-X.Y.Z-N**. These packages are not uninstalled during an uninstallation of Server Administrator.

In this case, if you try to install Server Administrator later by running the `sh srvadmin-install.sh` command, the following message is displayed:

```
Server Administrator version X.Y.Z is currently installed.
```

Installed components are:

- `srvadmin-omilcore-X.Y.Z-N`
- `srvadmin-hapi-X.Y.Z-N`

Do you want to upgrade Server Administrator to X.Y.Z? Press (y for yes) <Enter> to exit):

On pressing <y>, only those Server Administrator packages (in the above example), **srvadmin-omilcore-X.Y.Z-N** and **srvadmin-hapi-X.Y.Z-N** residing on the system are upgraded.

If you have to install other systems management components as well, the `sh srvadmin-install.sh` command has to be run once again.

What happens if I install the RPM package on an unsupported system or on an unsupported operating system?

If you try to install the RPM packages on an unsupported system or an unsupported operating system, you may see unpredictable behavior during the install, uninstall, or during use of the RPM package. Most of the RPM packages have been written and tested for supported systems and the Linux versions listed in the readme.

What daemons run on Red Hat Enterprise Linux and SUSE Linux Enterprise Server operating systems after Server Administrator is started?

The daemons that run on Red Hat Enterprise Linux and SUSE Linux Enterprise Server operating systems depend on what is installed and what is enabled to run. The following table displays the daemons that typically run for a full install:

Table 10. Daemons that Run on Red Hat Enterprise Linux and SUSE Linux Enterprise Server Once Server Administrator is Started

Daemon Name	Name in Red Hat Enterprise Linux and SUSE Linux Enterprise Server
For RPMs in the srvadmin-base directory	
dsm_sa_datamgr32d	DSM SA Data Manager — Server Administrator data manager daemon started by DSM SA Data Engine service.
dsm_sa_eventmgr32d	DSM SA Event Manager — Server Administrator event and logging daemon started by DSM SA Data Engine service.
dsm_sa_snmp32d	DSM SA SNMP daemon — Server Administrator SNMP daemon started by DSM SA Data Engine service.
dsm_om_shrsvc32d	DSM SA Shared Services — Server Administrator core daemon.
For RPMs in the SA-WebServer directory	
dsm_om_connsvc32d	DSM SA Connection Services — Server Administrator Web server daemon.
For systems that support DRAC 4: add-RAC4	
racsvc	DRAC 4 Administrator daemon.

What kernel modules are loaded when Server Administrator is started?

This is dependent on the type of systems instrumentation. The following table displays the kernel modules loaded when Server Administrator is started.

Table 11. Kernel Modules Loaded When Server Administrator Services are Started

Driver Name	Description
For a system with IPMI	
dell_rbu	BIOS Update Driver
ipmi_devintf	IPMI device driver
ipmi_msghandler	IPMI device driver
ipmi_si	IPMI device driver — For systems running Red Hat Enterprise Linux or SUSE Linux Enterprise Server
For a TVM system	
dcdbas	Systems Management Base Driver
dell_rbu	BIOS Update Driver
For an ESM system	
dcdbas	Systems Management Base Driver

Driver Name	Description
dell_rbu	BIOS Update Driver
For support of Server Administrator Storage Systems	
mptctl	Device driver for LSI RAID

When I run srvadmin-cm (Server Administrator Inventory Collector) it displays error messages. What do I do?

If you are using a system prior to 11G running on a supported 64-bit Linux operating system, the srvadmin-cm RPM installs only the 32-bit dependent RPMs. This is why the srvadmin-cm RPM displays error messages when it is run on a 64-bit operating system. To ensure srvadmin-cm functions as expected, the following RPMs must be preinstalled on servers prior to 11G running supported 64-bit Linux operating system.

glibc.i686

compat-libstdc++-i686

libstdc++-i686

zlib.i686

libxml2.i686

Emulex Network Adapter is not detected on Red Hat Enterprise Linux operating system. What do I do?

If you are using a system that is running Red Hat Enterprise Linux 5.9 (32-bit) operating system, the system experiences issues in detecting the Emulex Network Adapters if any of the following RPMs are missing,.

- kernel-headers-2.6.18-346.el5.i386.rpm
- glibc-headers-2.5-107.i386.rpm
- glibc-devel-2.5-107.i386.rpm
- gcc-4.1.2-54.el5.i386.rpm

For more information on Emulex Network Adapters, see the relevant Emulex Network Adapter or driver documentation.

Linux Installer Packages

This section lists the Linux installer packages.

Table 12. Meta RPMs

RPM	Description	Dependent packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-all	Meta package for installing all Server Administrator features	srvadmin-base, srvadmin-idrac, srvadmin-rac4, srvadmin-rac5, srvadmin-standardAgent, srvadmin-storageservices, srvadmin-webserver	Complete Server Administrator features	Y	Y	Y	Y
srvadmin-base	Meta package for installing the Server Agent	srvadmin-cm, srvadmin-omacore, srvadmin-smcommon	Server Instrumentation, SNMP monitoring, and Server Administrator CLI	Y	Y	Y	Y
srvadmin-standardAgent	Meta package for installing the Standard Server Agent	srvadmin-cm, srvadmin-ittunnelprovider, srvadmin-smcommon	Enabling remote management using Server Administrator Web Server	Y	Y	Y	Y
srvadmin-webserver	Meta package for installing the Server Administrator Web Server feature	srvadmin-smcommon, srvadmin-smweb, srvadmin-tomcat	Server Administrator Web Server for local and remote node management	Y	Y	Y	Y
srvadmin-storageservices	Meta package for installing the Server Administrator Storage Services feature	srvadmin-cm, srvadmin-megalib, srvadmin-smcommon, srvadmin-storage,	Storage Management using Server Administrator GUI/CLI	Y	Y	Y	Y

RPM	Description	Dependent packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
		srvadmin-storelib, srvadmin-sysfsutils					
srvadmin-rac4	Meta RPM for RAC4 components	srvadmin-omilcore, srvadmin-rac-components, srvadmin-rac4-populator, srvadmin-racadm4, srvadmin-racdrsc, srvadmin-racsvc	RAC 4 management using Server Administrator GUI/CLI, RAC4 tools	Y	Y	Y	Y
srvadmin-rac5	Meta RPM for RAC5 components	srvadmin-isvc, srvadmin-omilcore, srvadmin-rac-components, srvadmin-racadm4, srvadmin-racadm5, srvadmin-racdrsc	RAC 5 management using Server Administrator GUI/CLI, RAC5 tools	Y	Y	Y	Y
srvadmin-idrac	Meta RPM for iDRAC components	srvadmin-argtable2, srvadmin-deng, srvadmin-idrac-ivmcli, srvadmin-idrac-vmcli, srvadmin-idracadm, srvadmin-isvc, srvadmin-omcommon, srvadmin-omilcore, srvadmin-rac-components, srvadmin-racadm4, srvadmin-racdrsc	iDRAC management using Server Administrator GUI/CLI, iDRAC tools	Y	Y	Y	Y

RPM	Description	Dependent packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-server-snmpp	Meta package that contains dependency information to automatically pull in the Server Administrator Server SNMP feature	srvadmin-base,srvadmin-deng-snmpp, srvadmin-isvc-snmpp	Server SNMP feature	N	N	Y	Y
srvadmin-server-cli	Meta package that contains dependency information to automatically pull in the Server Administrator Server CLI feature	srvadmin-base, srvadmin-omacore	Server CLI feature	N	N	Y	Y
srvadmin-storageservices-snmpp	Meta package that contains dependency information to automatically pull in the Server Administrator Storage SNMP feature	storageservices, srvadmin-storage-snm	Storage SNMP feature	N	N	Y	Y
srvadmin-storageservices-cli	Meta package that contains dependency information to automatically pull in the Server Administrator Storage CLI feature	storageservices , srvadmin-storage-cli	Storage CLI feature	N	N	Y	Y

Table 13. Server Instrumentation and SNMP monitoring

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-omilcore	Core Install package that provides	pciutils,sm bios-utils-bin	Installing and functioning of Server	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
	tools for the systems management install packages		Administrator				
srvadmin-deng	Data Engine stores and manages objects for systems management	srvadmin-omilcore	Server Instrumentation and SNMP monitoring	Y	Y	Y	Y
srvadmin-hapi	Provides low-level hardware interface for systems management	None	Server Instrumentation	Y	Y	Y	Y
srvadmin-isvc	Provides systems management interface to local and remote systems management	srvadmin-deng, srvadmin-omilcore	Server Instrumentation and SNMP monitoring	Y	Y	Y	Y
libsmbios	Provides SMBIOS library to get standard BIOS tables	None	Installation and software updates	Y	Y	Y	Y
smbios-utils-bin	Provides SMBIOS Utility to get system information	None	Installation	Y	Y	Y	Y

Table 14. Packages needed for local management that are used by GUI and CLI components

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-omcommon	Common framework or libraries for GUI/CLI	srvadmin-omilcore	Server Administrator or GUI/CLI	Y	Y	Y	Y
srvadmin-omacore	Provides plugins that act as interfaces between back end and GUI/CLI. Also provides OM CLI tools.	srvadmin-omilcore	Server Administrator or GUI/CLI and infrastructure for software updates	Y	Y	Y	Y
srvadmin-xmlsup	XML support library	None	Server Administrator or GUI/CLI	Y	Y	Y	Y
srvadmin-libxslt	XSLT support library * Applicable on VMware ESX only	None	Server Administrator or GUI/CLI	Y	Y	Y	Y
srvadmin-cm	Change Management inventory collector. Feeds software inventory data to management station applications	srvadmin-omacore	Software inventory and updates	Y	Y	Y	Y
srvadmin-oslog	Management interface	srvadmin-omilcore	Replicating Server Administrator or Events in OS Log	N	N	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-omacs	Server Administrator or OMACS	srvadmin-omcommon srvadmin-omilcore	Common services bundled in helper library	N	N	Y	Y
srvadmin-ominst	Server Administrator or Core	None	Server Instrumentation Components	N	N	Y	Y

Table 15. Server Administrator Web Server (GUI) for Local and Remote Management

RPM	Description	Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-jre	Provides JAVA Runtime for web server	srvadmin-omilcore	Server Administrator or GUI	Y*	Y	Y	Y
srvadmin-iws	Server Administrator or Web server and GUI package	srvadmin-omilcore, srvadmin-omcommon, srvadmin-jre, openwsman-client, libwsman1	Server Administrator or GUI	Y*	O***	N	N
srvadmin-tomcat	Server Administrator or Web server	srvadmin-jre, srvadmin-omcommon, srvadmin-omilcore	Server Administrator or GUI	N	Y	Y	Y
openwsman-client	Openwsman client libraries	None	Server Administrator or GUI to manage remote nodes using WSMAN	Y	Y	Y	Y

RPM	Description	Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
libwsman1	Openwsman libraries used by client and server components	None	Openwsman support library	Y	Y	Y	Y

* — Not applicable for OM 7.0 supplemental pack for Citrix Xen 6.0.

** — Should be installed from the OS media for Red Hat Enterprise Linux 6 and SLES 11.

*** — Obsolete and replaced with **srvadmin-tomcat**

Table 16. Server Administrator Remote Enablement (Standard Agent)

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-itunnelprovider	The Small Footprint CIM Broker (SFCB) provider that enables remote management of the server	libcmpl0, openwsman-server, sbvim-sfcb, sbvim-sfcc	Enabling remote management of server	Y	Y	Y	Y
libwsman1	Openwsman libraries used by client and server components	None	Openwsman support library	Y	Y	Y	Y
openwsman-server	Openwsman server and service libraries *N/A on VMware ESX	None	Enabling remote management of server	Y	Y	Y	Y
sbvim-sfcb	Small Footprint CIM Broker (sfcb) -	None	Enabling remote management of server	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
	CIM server conforming to the CIM Operations over HTTP protocol. *N/A on VMware ESX						
sblim-sfcc	Small Footprint Common Information Model (CIM) Client Library (sfcc) Runtime Libraries *N/A on VmWare ESX	None	Enabling remote management of server	Y	Y	Y	Y
libcmapiCplusplus	Provides helper library to implement Common Manageability Programming Interface (CMPI) C++ + plugins into SFCB *N/A on VmWare ESX	None	Enabling remote management of server	Y	Y	Y	Y

* — Should be installed from the OS media for Red Hat Enterprise Linux 6 and SLES 11.

Table 17. Storage Instrumentation, SNMP Monitoring, GUI and CLI Plugins

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin- realssd*	Meta package for installing management libraries for PCIeSS Devices	None	Peripheral Component Interconnect Express Solid State (PCIeSS) Devices management	Y	Y	Y	Y
srvadmin- storage	Core interface library for storage management	srvadmin-deng, srvadmin-isvc, srvadmin-megalib, srvadmin-omilcore, srvadmin-smcommon, srvadmin-storelib	Storage instrumentation, SNMP monitoring and CLI (for storage management)	Y	Y	Y	Y
srvadmin- storelib	LSI utility libraries for storage management	srvadmin-storelib-sysfs	Storage instrumentation	Y	Y	Y	Y
srvadmin- storelib- sysfs	Provides library for interfacing with the kernel's sys filesystem. Used by LSI storelib libraries *N/A for VMware ESX	None	Storage instrumentation	Y	Y	Y	Y
srvadmin- sysfsutils	Provide utilities for interfacing with sysfs	None	Storage instrumentation	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
	file system. Used by the storage manageme nt libraries						
srvadmin- megalib	LSI utility libraries for storage manageme nt of PERC 4 controllers. *N/A for 64-bit OMSA installation, and VMware ESX.	None	Storage instrument ation of PERC 4 controllers	Y	Y	Y	Y
srvadmin- smcommo n	Common framework or libraries for GUI/CLI (for storage manageme nt)	None	Storage manageme nt using Server Administrat or GUI/CLI	Y	Y	Y	Y
srvadmin- smweb	GUI plugins for storage manageme nt	srvadmin- omcommo n, srvadmin- smcommo n	Storage manageme nt using Server Administrat or GUI	Y**	Y	Y	Y
srvadmin- storage-cli	Storage Manageme nt CLI Interface	srvadmin- storage	CLI interface access for Storage Manageme nt	N	N	Y	Y
srvadmin- storage- snmp	Storage Manageme nt CLI Interface	srvadmin- deng- snmp, srvadmin- storage	Storage- related SNMP queries and SNMP Traps	N	N	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-deng-snmp	Server Administrator or SNMP Framework	srvadmin-deng	Server Administrator or SNMP Framework	N	N	Y	Y
srvadmin-iscv-snmp	Server SNMP module	srvadmin-hapi, srvadmin-iscv	Server and Operating System related SNMP Queries and SNMP Traps	N	N	Y	Y

* — Obsolete - merged with srvadmin-storage

** — Not applicable for OM 7.0 supplemental pack for Citrix Xen 6.0.

Table 18. RAC Instrumentation, SNMP Monitoring, GUI and CLI Plugins

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-racsvc	RAC services to manage DRAC 4	setserial, srvadmin-omilcore	DRAC 4 instrumentation	Y	Y	Y	Y
srvadmin-rac-components	RAC data populator for DRAC 4	None	DRAC 4 instrumentation and SNMP monitoring	Y	Y	Y	Y
srvadmin-racadm4	Provides CLI tools for DRAC 4 administration	None	RAC CLI tools for DRAC 4	Y	Y	Y	Y
srvadmin-rac5-components	RAC Data populator for DRAC 5	srvadmin-omilcore, srvadmin-hapi, srvadmin-deng	DRAC 5 instrumentation and SNMP monitoring	N	N	Y	Y
srvadmin-racadm5	Provides CLI tools for DRAC 5	srvadmin-hapi, srvadmin-omilcore	RAC CLI tools for DRAC 5	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
	administration						
srvadmin-idrac7	RAC data populator for iDRAC7	srvadmin-argtable2, srvadmin-deng, srvadmin-idrac-vmcli, srvadmin-idracadm7, srvadmin-isvc, srvadmin-omcommon, srvadmin-omilcore, srvadmin-rac-components, srvadmin-racadm4, srvadmin-racdrsc	iDRAC7 instrumentation and SNMP monitoring	N	Y	Y	Y
srvadmin-idracadm	Provides CLI tools for iDRAC administration	srvadmin-argtable2, srvadmin-omilcore	RAC CLI tools for iDRAC	Y	Y	Y	Y
srvadmin-idracadm7	Provides CLI tools for iDRAC7 administration	srvadmin-argtable2, srvadmin-omilcore	RAC CLI tools for iDRAC7	N	Y	Y	Y
srvadmin-racdrsc	RAC CLI and Web Plugin to Server Administrator for RAC 4, 5 and iDRAC	None	RAC management using Server Administrator or GUI/CLI	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
srvadmin-rac-components	RAC SNMP components for RAC 4, 5 and iDRAC	None	RAC instrumentation and SNMP monitoring	Y	Y	Y	Y
srvadmin-rac4-populator	RAC Data populator for DRAC 4	srvadmin-omilcore	DRAC 4 instrumentation	Y	Y	Y	Y
srvadmin-argtable2	Library for parsing GNU style command-line argument. Used by RAC 5 and iDRAC packages	None	RAC CLI tools for RAC 5 and iDRAC management	Y	Y	Y	Y
srvadmin-idrac-ivmcli	Provides CLI tools that provide virtual media features from the management station to the iDRAC in the remote modular system	None	RAC CLI tools for virtual media feature	Y	Y	Y	Y
srvadmin-idrac-vmcli	Provides CLI tools that provide virtual media features from the management station to the iDRAC in	None	RAC CLI tools for virtual media feature	Y	Y	Y	Y

RPM	Description	OM Dependant packages	Required for	Systems Management Software			
				7.0	7.1	7.2	7.3
	the remote Rack and Tower system						